
Simple Glider Paper Airplane


Step-by-step folding instructions

1




1. Use a sheet of printer paper. Fold it in half the long way, then unfold.

2




2. Fold the top edge down to make a narrow strip.

3




3. Fold the strip down again.

4




4. Fold it down one more time. This heavy edge is the front of the glider.

5




5. Fold the plane in half behind, along the centre crease.

6




6. Turn the plane on its side, nose to the right.

7




7. Fold the top layer down along a line near the bottom. This is the first wing.

8




8. Turn the paper over.

9



9. Fold the second wing down the same way.



Seen from above, wings open

Done. Open the wings so they are flat and level, then launch it gently, slightly downward.